



## Insulating Gloves and Boots Tester



**Model: IGB**

This insulating gloves and boots test bench is used to test leakage current, insulation aging, power frequency of insulating gloves and boots. It can test 3 pairs for each time and to read leakage current of each pair in order to find which one is unqualified. There are trundles in the bottom which make more convenience for moving.

## Main Features

1. Input voltage:AC220V 50Hz
2. Output voltage:0~30KV
3. Capacity:3kVA
4. Test units:6 units each time
5. Test data:Display and print voltage data and leakage current data of each unit
6. Overcurrent protection: Overvoltage protection; User-defined time setting, display voltage data and leakage current data
7. Accuracy: Voltage  $\pm 2\%$  ( $\pm 3$  digits) Current  $\pm 2\%$  ( $\pm 3$  digits)
8. Weight: control unit 12kg; test bench 60kg



## Package List

1	Test car	1 Set
2	Test bench	1 Set
3	HV test transformer	1 Set
4	Test cable	1 Set
5	Manual book	1 Copy

